1000V INSULATED SOCKETS



1/4" Drive 12 Point SAE

Hex Size	Part No.	Overall Length in.	Weight lbs.
3/16"	V106-I	1 1/2	0.03
7/32"	V107-I	1 1/2	0.03
1/4"	V108-I	1 1/2	0.03
9/32"	V109-I	1 1/2	0.04
5/16"	V110-I	1 1/2	0.04
11/32"	V111-I	1 1/2	0.04
3/8"	V112-I	1 1/2	0.06
7/16"	V114-I	1 1/2	0.06
1/2"	V116-I	1 1/2	0.07
9/16"	V118-I	1 1/2	0.09

Individually insulated and tested to ASTM F1505 Standards.



1/4" Drive 6 Point Metric

Hex Size	Part No.	Overall Length in.	Weight lbs.
4mm	M604-I	1 1/2	0.03
4.5mm	M604.5-I	1 1/2	0.03
5mm	M605-I	1 1/2	0.03
5.5mm	M605.5-I	11/2	0.03
6mm	M606-I	1 1/2	0.03
7mm	M607-I	11/2	0.04
8mm	M608-I	11/2	0.04
9mm	M609-I	11/2	0.04
10mm	M610-I	1 1/2	0.04
11mm	M611-I	11/2	0.06
12mm	M612-I	11/2	0.06
13mm	M613-I	11/2	0.07
14mm	M614-I	11/2	0.09
15mm	M615-I	11/2	0.09

Individually insulated and tested to ASTM F1505 Standards. $\stackrel{\triangle}{\cong}$



Important: Insulated tools are an important link in the overall chain of safety when it comes to working on potentially energized material. Other important safety items include insulated gloves, insulated boots and arc flash prevention suits and clothing.